

How to install

1. To install end feed (E3F2), remove cover and mount back plate. Can be either back fed or end fed through KO's suitable 1/2" conduit. Replace cover.
2. To install Narrow Feed-In (E3F3), connect wire black-to-white, white-to-white in standard outlet box. The green wire is the grounding conductor.
3. To install the Split Wire Feed-In, (E3F4), follow procedure for E3F3. Connect the second 120 Volt circuit to the extra black wire. (Check direction of circuits with tester).
4. Attach cover plate of (E3F3 or E3F4) by tightening the 2 screws. The pressure connector feeds from both ends, and swivels for horizontal or vertical runs.
5. Insert the bare wire-ends into the Feed in until firmly seated into the concealed pressure-connectors. This assures positive electrical contact.
6. When Narrow Feed-In (E3F3 or E3F4) is used as an end feed only., insert provided sealing plug into the open end. Mounting screw guide holes are pre-punched every 8" along strip.
7. To mount tee (E3T1), establish its desired position. Use template on back of Tee as a guide to cut strip to proper length. Bare wires as before. Insert strip into Tee. Surface mount the Tee.
8. Secure the Electrostrip to the surface within 2" of the Tee fitting. Direction of arrows, imprinted on Electrostrip, should be as indicated to ensure proper connections.
9. To turn corners, bend strip first and mount strip from the corner back toward the Feed-In. Fasten with mounting screws 2" from each side of the corner.
10. Leave small excess in measuring to assure ample length. At end of Electrostrip run, use and End Cap (EC1) to insulate the conductors. Mount with the single screw in pre-drilled hole.

End Stripping

- A. Bend grounding strip back out of the way and score plastic 3/8" from end on all sides with knife.
- B. Grip thick portion of plastic with pliers and bend to approx. 45° until it cracks at scoring.
- C. Peel plastic from around wires.
- D. Grip centre of plastic with pliers and break off by bending back and forth. All bared wires should be 3/8" long for connection to accessories. Straighten all three wires.